







## IF NEEDED, HERE ARE THE STEPS ON HOW TO ADJUST THE BUMPER LATCH:

- 1. LOOSEN THE 1/2" LATCH ADJUSTER BOLT, USING 3/4" WRENCHES
- 2. USING A HAMMER, TAP/ PUSH IN THE LATCH ADJUSTER FOR A MORE TIGHTER LATCH CLOSURE, OR TAP/PULL OUT THE LATCH ADJUSTER IF BUMPER NO LONGER FULLY CLOSES
- 3. CHECK IF BUMPER CAN FULLY CLOSE
- 4. TIGHTEN FIRMLY THE 1/2" LATCH ADJUSTER BOLT
- 5. CONGRATULATION, THE LATCH IS ALL SET

## MAGNUM TRAILER & EQUIPMENT INC.

EGOII MENT INC.	
MACNIIV	
N. C.	

## 

DIMENSIONS A	WISE SPECIFIED ARE IN INCHES ICES ARE:
FRACTIONS	ANGLES
+/- 1/16"	+/- 1°
.XX"	.XXX"
+/- 0.03"	+/- 0.005"
DIMENSIONS TO	O SHARP POIN

SHEET NAME	TITLE					
LATCH ADJUSTMENT 17240 BUMPER ON 2017 FREIGHTLINER CASCADIA (P3)						
CURRENT CUSTOMER	STOCK NUMBER	VENDOR NUMBER	WEIGHT - LB.			
			409.			
	DRAWN BY	DRAWN DATE	REV.			
WO#	LS	2019-03-15	Α			
SCALE	MODELLER		NUMBER OF SHEETS			
1:10	MD	AA-51449	3			