

\*\* DRAWING PRINT SCALE CHECK - THIS LINE SHOULD MEASURE 10 3/8" LONG \*\*

## **INSTALLING MG-100/200/300**

- 1) SEE THE RADAR INSTALLATION SHEET IF RADAR IS EQUIPPED ON THE TRUCK.
- 2) OPEN HOOD AND REMOVE FACTORY TOW PINS FROM TRUCK
- 3) INSERT MOUNT BRACKETS INTO THE TOW SOCKETS (TOW PLATES SHOULD BE ON THE INSIDE OF THE BUMPER)
- 4) SLIDE FACTORY TOW PINS OR EQUIVALENT BOLT THROUGH THE TRUCK FRAME AND MOUNT BRACKETS.
- 5) TIGHTEN THE 5/8" NF STOVER NUT TO 128 FT-LBS TO SECURE THE BRACKETS IN PLACE
- 6) ATTACH THE MG-100 TO THE MOUNT BRACKETS USING THE TOP TWO ROWS OF SLOTS.
  SHIMS SHOULD BE PLACED BETWEEN THE GUARD AND THE MOUNT BRACKETS.
  HARDWARE: 5/8" NC X 1 3/4" BOLT, 5/8" WASHER & 5/8" STOVER NUT TIGHTEN TO 159 FT-LBS (6 PLACES)
- 7) THE GUARD IS NOW INSTALLED. THE HOOD CAN NOW BE CLOSED. REFER TO DRAWING #54268 FOR INSTALLING THE MG-200T/300T IF REQUIRED.





<b>MAGNUM TRAILER</b>
&
EQUIPMENT INC.

MAGNUN	A
--------	---

FRACTIONS CHART									
1/32 .03125 1/16 .0625 3/32 .09375 1/8 .125 5/32 .15625 3/16 .1875 7/32 .21875 1/4 .25	9/32 .28125 5/16 .3125 11/32 .34375 3/8 .375 13/32 .40625 7/16 .4375 15/32 .46875 1/2 .5	17/32 .53125 <b>9/16</b> .5625 19/32 .59375 <b>5/8</b> .625 21/32 .65625 <b>11/16</b> .6875 23/32 .71875 <b>3/4</b> .75	25/32 .78125 13/16 .8125 27/32 .84375 7/8 .875 29/32 .90625 15/16 .9375 31/32 .96875						

TOLERANCES ARE:					
FRACTIONS +/- 1/16"	ANGLES +/- 1°				
.XX" +/- 0.03"	.XXX" +/- 0.005"				
DIMENSIONS TO	SHARP POIN				

**UNLESS OTHERWISE SPECIFIED** 

SHEET INAME	IIILE						
BUMPER INSTALL MG SERIES BUMPER ON 2021 KENWORTH T-680							
CURRENT CUSTOMER	STOCK NUMBER		VENDOR NUMBER			WEIGHT - LB. 216.	
	DRAWN BY	DRAWN DATE		CHECKED BY	CHECKED DATE		REV.
WO#	MD	6/7/2021		LS	6/21/2021		Α
SCALE	MODELLER		DRAWING N			NUMBER OF	SHEETS
1:12	MD	AA-58591		2			

