INSTALLING 17277 ON INTERNATIONAL HX520

- 1. REMOVE FOG LIGHTS FROM OEM BUMPER (KEEP HARDWARE).
- 2. REMOVE OEM BUMPER FROM TRUCK (KEEP HARDWARE).
- 3. INSERT THE TWO TOW MOUNT ASSEMBLIES (58922) INTO THE TRUCKS TOW RECIEVERS.
- 4. SECURE THE TOW MOUNTS IN PLACE USING THE FACTORY TOW PINS.
- 5. ATTACH THE 17277 BUMPER TO THE TRUCK USING THE OEM HARDWARE IN ITS ORIGINAL CONFIGURATION.

 HARDWARE:
 3/4" UNF X 1 3/4" GR.8 HEX BOLT (4) (TORQUE TO 180 FT-LBS)
 3/4" UNF X 2 3/4" GR.8 HEX BOLT (4) (TORQUE TO 180 FT-LBS)
 3/4" GR.8 WASHERS (8)
 3/4" FLANGE NUTS(4)
- SECURE TOW MOUNTS USING SUPPLIED 3/4" GR.C STOVER NUTS (TORQUE TO 200 FT-LBS).
- 7. INSTALL FOG LIGHTS IN BUMPER USING THE OEM HARDWARE.


 HARDWARE:

 M8 X 25 CARRIAGE BOLT (2)

 M8 LOCK WASHER (2)

 M8 FLAT WASHER (2)

 M8 HEX NUT (2)
- 8. INSTALLATION IS COMPLETE.



MAGNUM TRAILER & EQUIPMENT INC.




	TRACTIONS CHART						
3/32 1/8 5/32 3/16	.03125 .0625 .09375 .125 .15625 .1875 .21875	9/32 .28125 5/16 .3125 11/32 .34375 3/8 .375 13/32 .40625 7/16 .4375 15/32 .46875 1/2 .5	17/32 .53125 9/16 .5625 19/32 .59375 5/8 .625 21/32 .65625 11/16 .6875 23/32 .71875 3/4 .75	25/32 .78125 13/16 .8125 27/32 .84375 7/8 .875 29/32 .90625 15/16 .9375 31/32 .96875			

FRACTIONS CHART

	TOLERANCES ARE:				
	FRACTIONS +/- 1/16"	ANGLES +/- 1°			
	.XX" +/- 0.03"	.XXX" +/- 0.005"			
Ī	DIMENSIONS TO SHARP POINTS				

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES

	INSTALL	17277 ON INTERNATIONAL HX520 SFA						
CURRENT CUSTOMER		STOCK NUMBER		VENDOR NUMBER		357.		
		DRAWN BY	DRAWN DATE		CHECKED BY	CHECKED DATE		REV.
	WO#	MD	7/20/2021		LS	8/04/2	/04/2021	
	ALE	MODELLER		DRAWING N			NUMBER OF	SHEETS
	1:12	MD		AA	-58899		1	



31/32 .96875

DIMENSIONS TO SHARP POINTS

MODELLER

MD

1:5

NUMBER OF SHEETS

AA-58899